ow_write

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Write a byte to the Onewire bus. This is a low level function allowing custom onewire operations.

Description

ow_write ($val)

Parameter

An **int** value containing the byte to send to the onewire bus

Return Values

none

Example

```
<pre><?

ow_write(10);
ow_write(11);
ow_write(0x55);

?>
```

See Also

ow_first() - Get the first device on the bus

ow_next() - Get next device on bus

ow_read_temp() - Read a temperature from a device

ow_reset() - Reset the onewire bus

ow_read() - Read a byte from the onewire bus

From:
https://www.wattmon.com/dokuwiki/ - **Wattmon Documentation Wiki**

Permanent link:
https://www.wattmon.com/dokuwiki/uphp/functions/ow_write?rev=1494497257

Last update: **2021/09/13 05:56**