

ftp_size

WM-MINI2, WM-MEGA FW >= 2.1137 WM-M2 FW >= 3.1137

Get the file size of a file on the remote FTP server

Description

```
int ftp_size ( string $filename )
```

Return the file size of a file on the remote server.

Parameters

\$filename: **String** file name with our without path of the remote file

Return Values

int: Size of the file in bytes if the value is above or equal to 0.

If the return value is -1, the function failed due to network or other issues.

If the return value is -2, the remote file does not exist.

Example

```
<?
$res = ftp_open("ftp.myserver.com",21,"myuser","mypassword");
if ($res) {

    // get the current directory on the server

    $res=ftp_size("myfile.txt");

    print("File size is: ".$res."\r\n");

    ftp_close();
}
?>
```

See Also

[ftp_open\(\)](#) - Open an FTP connection

[ftp_close\(\)](#) - Close an FTP connection

[ftp_command\(\)](#) - Send an FTP command

[ftp_error\(\)](#) - Get last FTP response code

[ftp_is_connected\(\)](#) - Check if the FTP connection is active

[ftp_is_connecting\(\)](#) - Check if the FTP connection is in the process of connecting

[ftp_is_busy\(\)](#) - Check if the FTP engine is busy

[ftp_list\(\)](#) - Lists a folder on the FTP server and outputs the result to the specified file

[ftp_status\(\)](#) - Get active transfer and connections status

[ftp_upload\(\)](#) - Upload a file

[ftp_download\(\)](#) - Download a file

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

http://wattmon.com/dokuwiki/uphp/functions/ftp_size

Last update: **2021/09/13 05:57**

