

# pin\_set

WMPRO FW >= 1.0 WMMEGA FW >= 2.0

Set a digital output to **value** 1 or 0

## Description

```
pin_set ( int $pin_index, int $value )
```

## Parameters

**\$pin\_index**: The internal pin number. Refer to [pin\\_configure\(\)](#) for the list of available pins. If the pin is not configured as a digital output this function does nothing.

**\$value**: 1 or 0 to set the digital output on or off

## Return Values

None

## See Also

[pin\\_configure\(\)](#) - Configure an IO pin as a digital input, output, or analog input

[pin\\_get\(\)](#) - Return the value of an IO pin

[adc\\_read\(\)](#) - Read an onboard ADC channel

From:

<http://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

[http://www.wattmon.com/dokuwiki/uphp/functions/pin\\_set?rev=1495210975](http://www.wattmon.com/dokuwiki/uphp/functions/pin_set?rev=1495210975)

Last update: **2021/09/13 05:56**

