

# send\_sms

WMPRO, WMMINI FW >= 1.1094 WMMEGA FW >= 2.1094

Send an SMS through a USB cellular dongle

## Description

```
int send_sms ( string $number , string $message )
```

This function attempts to send an SMS using a connect cellular dongle. This assumes that the dongle has already been recognized by [Wattmon](#) and that it has established a CDC connection. This will disconnect any Internet session (TCP/IP or otherwise), send the SMS and then restart the dongle.

## Parameters

**\$number**: Valid phone number

**\$message**: Message to be sent as SMS

## Return Values

- **Integer** 1 for success and 0 for error

## Example

### Send an sms

```
<pre><?
$res = send_sms("9551885991","Hello, sms");
if (!$res) {
    print("Failed to send the SMS.");
}
?></pre>
```

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

[https://www.wattmon.com/dokuwiki/uphp/functions/send\\_sms](https://www.wattmon.com/dokuwiki/uphp/functions/send_sms)

Last update: **2021/09/13 05:57**



