

spi_setcs

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Set the CS output of the SPI bus

Description

spi_setcs ()

Parameters

None

Return Values

None

See Also

[spi_clearcs\(\)](#) - Clear the CS output of the SPI bus

[spi_read\(\)](#) - Read a byte from the SPI bus

[spi_write\(\)](#) - Write a byte to the SPI bus

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

https://www.wattmon.com/dokuwiki/uphp/functions/spi_setcs

Last update: **2021/09/13 05:57**

