

debug

WMPRO FW >= 1.0 WMMEGA FW >= 2.0

Print to debug output

Description

`debug (string $output)`

Parameter

\$output: A **string** to output

Return Values

None

Example

```
<?
  debug("This is a debug message");
  // this will appear on the serial port if connected to a console
?>
```

See Also

[Serial Port Programming](#) - Some information on connecting and using the serial ports

[debugout\(\)](#) - Enable or disable debug messages

[error_reporting\(\)](#) - Set the debug output level

[log\(\)](#) - Print to the System Log (or optional file)

[print\(\)](#) - Print data to the current output stream such as a web page or terminal

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**



Permanent link:

<https://www.wattmon.com/dokuwiki/uphp/functions/debug>

Last update: **2021/09/13 05:57**