

fread

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Return bytes from a file or stream

Description

mixed fread (**int** \$handle, **int** \$bytes)

This function attempts to read a specified number of bytes from a file or stream. If less than the number of bytes are available it will return the available data. If no data is available it will return an empty string.

Parameters

\$handle: Valid handle of a previously opened resource

\$bytes: Limit to the number of bytes returned

Return Values

- **string** containing the data requested from the resource
 - The length of the returned **string** depends on available data (**0 to \$bytes**)
- **int** 0 for error

Example

Read the 32 byte MD5 hash from file /md5.txt:

```
<?
$fp=fopen("/md5.txt","r");
if ($fp) {
    $data=fread($fp,32); // read 32 bytes from the file
    print($data);
    fclose($fp);
} else {
    print("File open failed\n");
}
?>
```

See Also

[fgets\(\)](#) - Return a single line from a file or stream, with optional size limit

[fwrite\(\)](#) - Write data to a file or stream

[fsockopen\(\)](#) - Open an internet socket connection with optional timeout

[fopen\(\)](#) - Open a file for reading or writing

[f485open\(\)](#) - Open the RS-485 port at the specified baud rate and parity

[fseropen\(\)](#) - Open the serial port at the specified baud rate with optional parameters

[fclose\(\)](#) - Close a file, stream or socket

[fseek\(\)](#) - Position the file pointer in an open file

[ftell\(\)](#) - Return the current position of a file read/write pointer

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

<https://www.wattmon.com/dokuwiki/uphp/functions/fread?rev=1491312091>

Last update: **2021/09/13 05:56**

