

ftp_error

FW >= 1295

The ftp_error() function returns the internal FTP error number

Description

int ftp_error ()

Parameter

None

Return Values

int: Return value is explained in the below table.

Value	Error Name	Description
0	FTP_RESOLVE_OK	DNS Resolution OK
1	FTP_RESOLVE_ERROR	Unable to resolve server
2	FTP_TCP_ERROR	Unable to open socket
3	FTC_TCP_ERROR_TIMEOUT	Timeout while waiting for reply
4	FTC_TCP_ERROR_TLS_TIMEOUT	Timeout while establishing secure connection
5	FTC_COMMAND_ERROR_TIMEOUT	Error while awaiting command reply
6	FTC_ERROR_INVALID_PASSWORD	Password is invalid
7	FTC_TCP_DISCONNECT	The command or data channel socket was closed
8	FTC_ERROR_INVALID_COMMAND	Invalid command received

From:

<http://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

http://wattmon.com/dokuwiki/uphp/functions/ftp_error

Last update: **2024/07/16 04:34**

