

# ftp\_open

WM-MINI2, WM-MEGA FW >= 2.1137 WM-M2 FW >= 3.1137

Open a connection to an FTP server

## Description

```
int ftp_open ( string $host , int $port , string $username , string $password [, int  
$secure ])
```

Connect to the server and return the response code.

## Parameters

**\$host:** **String** containing the host name or IP address of teh FTP server

**\$port:** **Int** FTP port number

**\$username:** **String** containing the FTP username

**\$password:** **String** containing the FTP password

**\$secure:** **Int** whether to use TLS (1) or not (0)

## Return Values

**int:** Returns 1 if FTP connection was successful and 0 if it failed.

## Example

```
<?  
    $res = ftp_open("ftp.myserver.com",21,"myuser","mypassword");  
    if ($res) {  
        print("connected to FTP server!!");  
        ftp_close();  
    }  
?>
```

## See Also

[ftp\\_close\(\)](#) - Close an FTP connection

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**



Permanent link:

[https://www.wattmon.com/dokuwiki/uphp/functions/ftp\\_open?rev=1561791548](https://www.wattmon.com/dokuwiki/uphp/functions/ftp_open?rev=1561791548)

Last update: **2021/09/13 05:56**