

# mem\_usage

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Write memory usage to standard output

## Description

mem\_usage ( )

This function will output a summary list showing how memory is currently being used

## Parameters

None

## Return Values

None

## Example

```
<?
  mem_usage();
?>
```

Typical example output (the numbers will vary depending on the current state of the system):

```
DEVICES: 159
DEVICETYPE: 840
CRON: 0
GLOBAL: $_GLOBALS
GLOBALS: 3176
CACHE: 1078
TOTAL: 5253
```

## See Also

[freemem\(\)](#) - Return free memory space

[mem\\_dump\(\)](#) - Write the current memory map to /dump.txt

## Memory Limit Challenges to Programming the Wattmon

From:

<https://wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

[https://wattmon.com/dokuwiki/uphp/functions/mem\\_usage](https://wattmon.com/dokuwiki/uphp/functions/mem_usage)

Last update: **2021/09/13 05:57**

