

snmp_trap_send

WMMEGA,MINI3 >= 2.1175 WM-M2 >= 3.1175

Send an SNMP Trap message

Description

int snmp_trap_send (**string** \$message)

Send a message via SNMP Trap to the configured trap server. This will be transmitted as an ASCII message.

Parameter

\$message: A **string**

Return Values

int: 0 if it failed, or 1 if it succeeded

Example

```
<?
$res = snmp_trap_send("Voltage exceeded threshold");
?>
```

See Also

From:

<https://www.wattmon.com/dokuwiki/> - **Wattmon Documentation Wiki**

Permanent link:

https://www.wattmon.com/dokuwiki/uphp/functions/snmp_trap_send

Last update: **2021/09/13 05:57**

