

strtoupper

WMPRO, WMMINI FW >= 1.0 WMMEGA FW >= 2.0

Return the UPPERCASE version of a **string**

Description

string strtoupper (string \$str)

This function converts all alphabetic characters in **str** to UPPERCASE

Parameter

\$str: The input **string**

Return Values

UPPERCASE **string**

Example

```
<?
  $str="Mary Had A Little Lamb and She LOVED It So";
  $str=strtoupper($str);
  print $str; // Prints "MARY HAD A LITTLE LAMB AND SHE LOVED IT SO"
?>
```

See Also

[charat\(\)](#) - Return the ASCII code for a character in a **string** at an index

[strlen\(\)](#) - Return the length of a **string**

[strpos\(\)](#) - Return the position of the first occurrence of a needle in a haystack

[strrpos\(\)](#) - Return the position of the last occurrence of a needle in a haystack

[strtolower\(\)](#) - Return the lowercase version of a **string**

[substr\(\)](#) - Return part of a **string**

[ucfirst\(\)](#) - Convert a **string** to lowercase except for the first character of each word

From:
<https://www.wattmon.com/dokuwiki/> - Wattmon Documentation Wiki



Permanent link:
<https://www.wattmon.com/dokuwiki/uphp/functions/strtoupper?rev=1495820565>

Last update: **2021/09/13 05:56**